



A Safe Fleet Brand

## **Installation Instructions**

### **RVS-CL**

### **Clearance Light Backup Camera**

1. Locate and mark camera mounting position at rear of vehicle.
2. Drill hole (0.375") in vehicle to run cabling through.
3. Stick adhesive pad onto back of camera.
4. Disconnect 5 pin connection, fish wiring through hole then reattach 5 pin connection.
5. Mount camera with adhesive pad and then screw in.
6. Connect power wire to ignition power and ground wire to chassis ground.
7. Connect 5 pin connection to camera cable and run cabling through vehicle.

