# Wireless Adaptor System

## **HD Waterproof Wireless Transmitter and Receiver**

## **RVS-DS66**

Use this transmitter & receiver set to make any of our wired cameras and monitors wireless.

This also works with our Mobile Mule™ line, so you can have wireless DVR cameras.


The RVS-DS66 works at a range of 100' and is waterproof with an IP69K rating, allowing you to install it outside your vehicle.

Just press and hold the "PAIR" buttons to activate this system in seconds.



#### **Monitor**

- 1. Connect receiver to monitor
- 2. Connect receiver to power (steady red light will indicate power is on)
- 3. Connect monitor/DVR to power
- 4. Press "PAIR" and hold for 3 seconds (red light will flash slowly as device enters pairing state)
- 5. Pairing is completed once red light stops flashing and green light turns on



### Camera

- 1. Connect transmitter to camera
- 2. Connect transmitter to power (steady red light will indicate power is on)
- 3. Connect camera to power
- 4. Press "PAIR" and hold for 3 seconds (red light will flash slowly as device enters pairing state)
- 5. Pairing is completed once red light stops flashing and green light turns on

